

Centro RotrLink Counter (post January 2016)

Assembly Instructions



1



Carefully lay counter top on floor, with fixing points uppermost.

2



With the labelled '1' end of the post towards the counter top, position female fitting of post centrally over male fitting of triangular fixing plate. Rotate until post drops into position, continue rotating post clockwise through 90° to secure. Repeat for second post.

3



With the steel fixing strip of curved profile adjacent to counter top, slide first curved profile between posts, in channels aligned to cut out of triangular fixing plates.

Ensure profile sits on underside of counter top and tighten grub screws to clamp in position.

4



Assemble vertical profiles to the curved profile ensuring that the graphic fixing strip is adjacent to the post and facing forward (convex side).

5



Attach second curved profile to both posts and both verticals, ensuring the steel fixing strip is uppermost. Tighten remaining clamp screws to secure in place.

6



Position male fitting of base plate centrally over female fitting of post. Rotate until base drops into position, continue rotating clockwise through 90° to secure.

Repeat for second base plate.



7



Carefully turn completed assembly onto its base plates and attach your graphic to convex side of system, working from one post to the other.

