

Centro Podium Table Assembly Instructions

1



With countersunk holes in Podium top facing upwards, align with circular plate holes and fixing holes in the 8-way post. Insert 4 screws supplied and tighten.



2



Position 220mm straight profiles approximately 150mm from the top and bottom of the 8-way post and at 90° to the cut out in the table top (as pictured bottom left). Insert into 8-way post and secure by tightening expanding clamp grub screw.



3



Affix assembled Podium Table to Centro system by inserting into 8-way post and tightening expanding clamp grub screws.

