


ST Literature Presenter Assembly Instructions

1



Turn both latches to unlock the system.

2



Pull up the system away from base.

3



Re-engage both latches to lock the system.

